






PUFİN INSTALLATION GUIDE ⚡ Voltaj / voltage: 220 – 240 VAC Frekans/Frequency 50-60 HZ

Bu armatür ilgili standartlara uygun dizayn edilmiş ve üretilmiştir. Montajı yalnızca, teknik personeller tarafından talimatlara uygun yapılmalıdır. This luminaire has been designed and manufactured according to relevant standards. For luminaires with non-user replaceable light sources, the light sources must be replaced by the manufacturer, his service agent or other similarly qualified people.


IP20




OFF

Kablo Kesim Boyları
Cable Cutting Dimensions


1- Armatür tavan içine alınır.
The armature is enclosed in the ceiling



2- Armatürün elektrik bağlantısı yapılır.
The electrical connection is made.



3- Armatür tavan içindeki yerine alınarak montaj tamamlanır.
Installation is completed by fitting the armature in the ceiling.



Bu talimat armatürle ilgili ileride oluşabilecek bakım işleri için saklanmalıdır. Yukarıdaki talimatlara uygunsuzluk otomatik olarak EAE'nin sorumluluğu dışındadır. The present intrunction paper has to bekept for any future maintenance oparation the luminate. Non compliance with the above will automatically release EAE's from any responsibility.